

titron[®] BAUR automatic cable fault location system



Image of the cable test van - incl. options

The intelligent system for cable fault location, testing and diagnostics

- Convenient to operate with simple user guidance
- High-performance technology and the highest safety standard
- Remote control with the BAUR Fault Location App*
- Compact version for installation in small vehicles

The new BAUR titron[®] is a new generation cable fault location system. It is a fully automatic, centrally controlled and intelligent system for cable fault location, cable testing and diagnostics*.

Thanks to the novel operational concept and the high-performance technology, the **titron**[®] system is able to carry out measurements more rapidly, more easily and with higher precision. The test van's functions are centrally controlled via the BAUR titron software. The intuitive user interface that is perfectly adapted to the cable fault pre-location process supports the operator throughout the entire work process.

Fault location. Recommendations for the cable fault location process are generated based on a multitude of factors that link the system, in an intelligent manner, to an algorithm specifically designed for this purpose. Nevertheless, the user is still, at any time, able to override the given specifications of the system and to carry out the measurement process based on his own experience and knowledge. The well-proven and continuously enhanced methods are available for the cable fault location as well as the newly developed Conditioning SIM/MIM method which makes it even more effective and quick to locate wet cable faults that are difficult to detect.

Testing and diagnostics*. The voltage test and diagnostic functions* are important supplements to the cable fault location system. It is in particular a good opportunity to carry out partial discharge testing for the condition evaluation of the cable system after work has been conducted on buried cables.

High voltage and functions

- DC voltage up to 40 kV (up to 80 kV*)
- VLF truesinus[®] up to 57 kV_{rms}*
- Surge voltage up to 32 kV
- Cable testing
- Cable sheath testing
- Cable fault location
- Tracing
- Cable diagnostics*:
 - Dissipation factor measurement
 - Partial discharge testing and location

Higher efficiency through innovative technology

- BAUR Fault Location App* for remote control of the cable fault pin-pointing process
- Compact, fully-equipped testing and fault location system titron[®] 40-1C for installation in very small vehicles
- Interface to GIS systems*
- Surge energy up to 3000 J, complete surge energy on all voltage levels
- Precise fault location methods for every type of fault and various cables, e.g.
 - SIM/MIM the most effective method for cable fault location
 - Conditioning-SIM/MIM helpful in locating wet faults that are difficult to detect
 - DC-SIM/MIM for flashover faults and intermittent faults
 - Envelope curve display for intermittent faults – even small changes in impedance are made visible and saved.
 - 3-phase current coupling methods* for the fault location in branched networks
- Quickest surge sequence with maximum power surge for efficient and rapid fault pin-pointing
- Maximum safety for the operator and the system

* Options

BAUR GmbH · Raiffeisenstraße 8, 6832 Sulz, Austria · T +43 (0)5522 4941-0 · F +43 (0)5522 4941-3 · headoffice@baur.at · www.baur.eu

Distributed by RCC Electronics Limited





titron[®] State of the art in cable fault location



Image of the cable test van - incl. options

The new intuitive operational concept

- Intuitive modern user interface no long introduction or familiarisation period is required
- Automated processes for quick and reliable cable fault location
- Optimal operator support during cable fault location provided by the Smart Cable Fault Location Guide
- BAUR GeoBase Map*:
 - Unique combination of road maps, including the cable route
 - GPS-based system location determination
 - Cable routes and cable faults displayed on the map
- ↗ Cable Mapping Technology CMT: Overview of cable accessories and faults in relation to the cable length
- All data on the cable route such as geographic position*, voltage level, joints, all measured values, etc. are automatically saved and can be accessed at any time.
- Quick and easy compilation of clear and precise measurement records with freely selectable company logo, comments and figures of the measured curves.

Easy and convenient to operate

- 19" monitor for high productivity and greater clarity during the evaluation (a second monitor is available as an option)
- Standard, convenient operation by means of a mouse and keyboard
- ↗ Proven Windows operating system
- Installation of office software, e.g. MS Office programs, company-internal ERP systems, GIS and web applications, is possible.
- Printers, laptops and data carriers can be connected via standard connections.
- GIS interface* enables an exchange of cable data between your GIS system and the BAUR system software.

Central automatic control with complete system monitoring

- Central system control via the powerful industrial PC
- Highest level of efficiency and measurement precision through the optimally adjusted measurement path, combined with modern digital signal processing
- Extremely high reliability by monitoring and recording all system events
- Quick start: ready for operation in just a few seconds



Cable test vans online

- Online support via the Internet
 - With your permission, BAUR's customer service department can access the computer of your cable test van, identify your problem and quickly find a solution.
 - During the fault location, your engineers can share the desktop with the test engineer on site and support him in the analysis of the measurement results (where applicable, a licence for a desktop-sharing program may be required).

* Option

The names of products are the trademarks or brand names of the relevant companies.

Data sheet: BAUR GmbH \cdot 826-114-10 \cdot 03.2018 \cdot Subject to modifications

Distributed by RCC Electronics Limited

Page 2/7



www.rcce.com 1-800-668-6053



titron[®] Find your cable fault with just a few clicks!

Smart Cable Fault Location Guide

- The intelligent Smart Cable Fault Location Guide leads the user step-by-step quickly and efficiently to the cable fault.
- A special algorithm continuously analyses the current measurement results which it uses to generate optimum recommendations for the user regarding the further procedure required to reliably locate the cable fault.
- Automatic fault analysis with clear graphical presentation giving a better overview.
- Test voltage wizard:
 - The system recommends voltage values according to the cable data and the fault type.
 - The test voltages can be defined according to the user.
- Automatic cursor positioning at the cable end and at the fault.
- Automatic adjustment of method-related parameters for quick and efficient fault location.
- ↗ Clear graphical presentation of the measurement results with helpful functions for the analysis.

All this **with full flexibility for experienced users!** The experienced test engineer can use his know-how directly at any point during the measurement process and select a user-specific procedure.



Comprehensive safety concept in accordance with the latest standards

- Safety concept in accordance with EN 61010-1 and EN 50191
- Monitoring of all safety-relevant parameters (protective and auxiliary earthing, rear door and HV connection sockets)
- Red and green signal lamp to indicate the operating state
- Emergency stop button in the operating area and optional external emergency stop feature
- ↗ Key-operated switch against unauthorised operation
- All operation-related error messages are displayed clearly on the screen and are immediately visible to the user.



Image of the cable test van - incl. options

Data sheet: BAUR GmbH · 826-114-10 · 03.2018 · Subject to modifications



Page 3/7



titron[®] Gentle and safe pin-pointing with the BAUR Fault Location App*



Remote control of the titron® via smartphone or tablet

During pin-pointing, all essential functions of the titron® can be remotely controlled via the BAUR Fault Location App:

- Switching the surge voltage generator on and off
- Setting the surge voltage and the surge sequence (5 20 pulses/min, single surge)
- Selecting the surge voltage range

This way, the operator has the possibility of only switching on the high voltage when he reaches the pre-located fault location. Once the fault has been located, the high voltage can be switched off again. Through this, the stress on the cable and the system is reduced to the necessary minimum and the level of safety is significantly increased.

Advantages

- ↗ Less stress on the cable
- ↗ Less wear and tear to the system due to significantly reduced operating time
- High level of safety for the testing personnel and the environment
- More efficient fault pin-pointing due to the monitoring and adjustment of voltage parameters directly on site during the pin-pointing process

Location and fault position at a glance

The cable data of titron® are transmitted to the Fault Location App and, in combination with the street map, are displayed in the app. This allows the operator always to have the latest information on the

- cable route (if available)
- ↗ pre-located fault position
- Iocation of the cable test van

Monitoring and adjusting the measurement parameters during the fault location

In the fault location mode, the operator always has an overview of the most important measurement parameters:

- ↗ High voltage status
- Output voltage, max. permissible voltage
- Surge sequence, surge energy, duration of the measurement
- SSG capacitor charge and discharge curve
- * Option

Page 4/7



Supported devices

- iPhone, iPad, iPad mini, iPod touch (iOS from version 9.2)
- Smartphones or tablets with Android operating systems from version 4.0.3

Data sheet: BAUR GmbH · 826-114-10 · 03.2018 · Subject to modifications





www.rcce.com 1-800-668-6053



Technical data

			titron [®]	titron®	titron®
			3-pnase	I-pnase	compact
I. High voltage					
Surge voltage					
Surge voltage ranges	0 – 8 kV, 0 – 16 kV, 0 – 32 kV		\checkmark	\checkmark	\checkmark
Surge energy	3,000 J @ 8, 16 and 32 kV		Surge energy of	Surge energy of	Surge energy o
	2,050 J @ 8, 16 and 32 kV		choice	choice	choice
	1,540 J @ 8, 16 and 32 kV				
Surge capacitor extension	SZ 1550: SZ	Z 2650:	Option	Option	Option
With surge energy class 3,000 J:	1,820 J @ 4 kV 2,	,890 J @ 4 kV			
With surge energy class 2,050 J:	1,580 J @ 4 kV 2,	,660 J @ 4 kV			
With surge energy class 1,540 J:	1,460 J @ 4 kV 2,	,530 J @ 4 kV			
Surge sequence	5 - 20 pulses/min, single surg	je	\checkmark	\checkmark	\checkmark
Capacitor charge time	Max. surge voltage 32 kV in 3	3 s	\checkmark	\checkmark	\checkmark
DC voltage and VLF voltage					
DC voltage	$0 - 40$ kV, $I_{max} = 50$ mA		\checkmark	\checkmark	\checkmark
	0 – 80 kV (by integration of PC	GK AC/DC HV test set)	Option	Option	Option
VLF high voltage generator vio	bla		Option	Option	Option
DC voltage	0 to ±60 kV				
VLF voltage	truesinus® 0 – 42.5 kV _{rms} Re	ectangular 0 – 60 kV			
Frequency range	0.01 – 0.1 Hz				
Max. capacitive load	up to 10 μF; 0.85 μF @ 0.1 Hz	z at 44 kV _{rms}			
	2.7 μF @ 0.03 Hz at 44 kV $_{\text{rms}}$;	7.7 μF @ 0.01 Hz at 44 $kV_{\mbox{\tiny rms}}$			
VLF high voltage generator PH	IG 70		Option	Option	Option
DC voltage	0 to \pm 70 kV; I _{max} = 10 mA @ 7	70 kV; 90 mA @ 20 kV			
VLF voltage	truesinus® 0 – 38 kV _{rms} Re	ectangular 0 – 57 kV			
Frequency range	0.01 – 1 Hz				
Max. capacitive load	up to 20 μF; 3 μF @ 0.1 Hz at	38 kV _{rms}			
VLF high voltage generator PH	IG 80		Option	Option	Option
DC voltage	0 to ±80 kV; I _{max} = 1.8 mA @ 3	80 kV; 90 mA @ 20 kV			
VLF voltage	truesinus® 0 – 57 kV _{rms} Re	ectangular 0 – 80 kV			
Frequency range	0.01 – 1 Hz				
Max. capacitive load	up to 20 μF ; 1.2 μF @ 0.1 Hz a	at 57 kV _{rms}			
	3 $\mu F @$ 0.1 Hz at 38 kV $_{\mbox{\tiny rms}}$				
II. Cable testing					
DC voltage testing	up to 40 kV, $I_{max} = 50 \text{ mA}$		\checkmark	\checkmark	\checkmark
	60 / 70 / 80 kV*		Option	Option	Option
VLF testing	truesinus® 38 / 44 / 57 kV _{rms} *	*	Option	Option	Option
Cable sheath testing	up to 40 kV, I _{max} = 50 mA Max. voltage adjustable		\checkmark	\checkmark	\checkmark
III. Cable fault location	5				
Insulation resistance measure	ment				
Measurement range	0 Ohm – 5 GOhm Vo	oltage: up to 1,000 V	\checkmark	\checkmark	√
3-phase measurement L-N, L-L	via HV connection	- • •	\checkmark	_	
3-phase measurement L-N, L-L	via LV connection with TDR co	onnection cable, 50 m	Option	Option	\checkmark

 \checkmark = included in standard delivery / Option = available as an optional extra / – = not available

* see optional high-voltage sources above

Data sheet: BAUR GmbH \cdot 826-114-10 \cdot 03.2018 \cdot Subject to modifications



Tec	hnical	data
	micu	aucu

BAUR ensuring the flow

				titron® 3-phase	titron® 1-phase	titron® compact
III. Cable fault locat	tion					1
Pulse reflectometry						
Automatic calculation of	the cable length and fault dist	ance		\checkmark	\checkmark	\checkmark
Measurement mode	 Automatic measurement 	 Automatic measurement mode 				
	 Differential measuremer 	nt to compare record	led traces			
	 Mean value calculation; continuous measurement 					
	 Stop after recording the change 					
	Envelope curve display ferret	or the location of int	ermittent faults			
Pulse voltage:	20 – 200 V	Pulse width:	20 ns – 1.3 ms			
Output impedance:	8 – 2,000 Ohm	Data rate:	400 MHz			
Resolution:	$0.1 \text{ m} (\text{at v}/2 = 80 \text{ m}/\mu\text{s})$	View range:	10 m – 1,000 km			
Velocity of propagation (v/2)	20 – 150 m/µs	Accuracy:	0.1% relating to the measurement result			
Pre-location methods						
TDR Time Domain Ref	lectometry			\checkmark	\checkmark	\checkmark
 3-phase measurem 	ent L-N, L-L via HV connectior	l		\checkmark	-	-
 3-phase measurem 	ent L-N, L-L via LV connection	with TDR connectio	n cable, 50 m	Option	Option	\checkmark
 SIM/MIM secondary/ 	multiple impulse method up t	to 32 kV		\checkmark	\checkmark	\checkmark
 DC-SIM/MIM seconda 	ary/multiple impulse method	used in DC mode up	to 32 kV, I _{max} = 120 mA	\checkmark	\checkmark	\checkmark
 Conditioning-SIM/M 	IIM fault conditioning with sub	sequent secondary/	multiple impulse method	\checkmark	\checkmark	\checkmark
ICM impulse current m	nethod up to 32 kV			\checkmark	\checkmark	\checkmark
 DC-ICM impulse curre 	nt method used in DC mode u	p to 32 kV, $I_{max} = 12$	0 mA	\checkmark	\checkmark	\checkmark
 Decay decay method u 	up to 40 kV	max		\checkmark	\checkmark	\checkmark
 Determination of browned in the second second	eakdown voltage up to 40 k	V*		\checkmark	\checkmark	\checkmark
 3-phase current coup For pre-locating cable f comparison method, co 	pling methods faults in branched low-voltage omparison method type 1 and	and medium-voltag	ge networks: Differential	Option	_	_
 Measuring bridge m (shirla – BAUR sheath t 	easurement for the pre-locat test and fault location device)	tion of cable and cab	ble sheath faults	Option	Option	Option
Fault conditioning thro	ough burning					
Voltage	0 – 10 kV, up to 32 A; 2.3 k	VA		Option	Option	Option
Voltage	0 – 15 kV, up to 90 A; 6 kVA	ł		Option	Option	Option
Pin-pointing methods						
 Acoustic pin-pointing: Voltage ranges: 0 – 8 kV, 0 – 16 kV, 0 – 32 kV** 			\checkmark	\checkmark	\checkmark	
 Universal receiver, ground microphone, headphones 			Option	Option	Option	
 Step voltage method 	d up to 40 kV, $I_{max} = 50 \text{ mA}$			\checkmark	\checkmark	\checkmark
– Universal receiver / KMF 1 earth fault locator			Option	Option	Option	
Tracing, audio frequency methods (twist method and minimum distortion method)			Option	Option	Option	
Equipment for audio fr	equency methods and tracing					
– TG 600 integrated a	audio frequency transmitter, 6	00 VA		Option	Option	-
– TG 20/50 mobile a	udio frequency transmitter, 20	VA/50 VA		Option	Option	Option
 Universal receiver. 	SP 30 search coil			Option	Ontion	Option

 \checkmark = included in standard delivery / Option = available as an optional extra / – = not available

* See optional high-voltage sources in section "I. High voltage"

** For surge voltage data and available options, see section "I. High voltage"

Page 6/7



www.rcce.com 1-800-668-6053



Technical data

		titron®	titron®	titron®
		3-phase	1-phase	compact
IV. Safety and protect	ctive features			
Safety standard	in accordance with EN 50191 and EN 61010-1			
Electrical safety	Overvoltage category IV/300			
Safety monitoring	Protective earthing, operational earthing, auxiliary earthing, potential monitoring, HV connections, rear doors, emergency off button	\checkmark	\checkmark	\checkmark
Monitoring of the supply voltage	Overvoltage protection, undervoltage protection			
Isolation transformer	5 kVA or 7 kVA with switch current limiter	Option	Option	Option
V. System data				
Phase and device select	ion			
Automatic phase and devi	ce selection	\checkmark	\checkmark (Device selection)	_
HV connection				
– 3 x 1-phase HV conn	ection cable, 50 m	\checkmark	_	-
– 3 x 1-phase HV conn	ection cable, 80 m	Option	_	_
 – 1-phase HV connection 	ion cable, 50 m	_	\checkmark	\checkmark
– 1-phase HV connecti	ion cable, 80 m	_	Option	Option
– Cable drum rack		\checkmark	\checkmark	 ✓
 Cable drum rack with 	h motor drive	Option	Option	Option
LV connection		1	1	
 LV connection panel 	to connect external measuring devices	\checkmark	\checkmark	\checkmark
 TDR connection cabl 	e. 3-phase, 50 m. on hand drum, measurement category CAT IV/600 V	Option	Option	· · · · · · · · · · · · · · · · · · ·
External emergency off un	it with signal lamps, incl. connection cable, 50 m	Option	Option	Option
Operating system and d	lisnlav			
Operating system	Windows 7 Illtimate 32-bit (or higher)			\checkmark
Memony	A GB RAM		\checkmark	
Hard dick	Principal and the standard and the stand	\checkmark		
	TET monitor 10" screen recolution: 1280 x 1024			
Dispidy	Second TET monitor 10"	Ontion	Ontion	Ontion
Software and data man	acement	Option	Option	Option
User interface	ayeilicht			
Data expert format			\checkmark	\checkmark
Data export format		V		
	USD	Ontion	Ontion	Ontion
GIS IIIteriace		Option	Option	Option
BAUR Geobase Map	Full version	Option	Option	Option
BAUK Fault Location App	For remote control of the surge voltage generator	Option	Option	Option
		Option	Option	Option
Systems supply and ope	anating conditions			
Input voltage	190 – 264 V, 47 – 63 HZ		\checkmark	\checkmark
Max. power consumption		\checkmark		
Ambient temperature	HV area: -20 °C to $+50$ °C; operating area: 0 °C to $+50$ °C			
Storage temperature	-20 °C to +60 °C	0.11		
Synchronous generator	7 kVA, 230 V	Option	Option	Option
Electronic generator	5 KVA, 230 V	Option	Option	Option
Battery-Power system	For battery operation, battery capacity 5 kWh, 230 V	Option	Option	Option
Fan heater	230 V, 2,000 W	Option	Option	Option
Air condition	230 V	Option	Option	Option
Weight		_		_
Standard version		From 800 kg	From 800 kg	From 450 kg

Data sheet: BAUR GmbH \cdot 826-114-10 \cdot 03.2018 \cdot Subject to modifications

